BOILERS

REDUCING FUEL COSTS IN A STEAM-GENERATING SYSTEM

ith rising fuel and electrical costs, energy

savings and water conservation are more important to a facility's economics than ever before. Energy costs typically account for as much as 60% of a facility's overhead, and the largest energy consumer is often the steam generating plant. Therefore, economics demand that attention must be focused on ways of improving the overall efficiency of the steam-generating equipment. This article will review methods of reducing fuel cost by minimizing boiler water blowdown rates. The article will also review calculations to determine fuel costs at current, versus proposed blowdown rates, as well as present an example of how to directly calculate fuel savings.

Boiler Blowdown

Every boiler has limits of how concentrated the boiler water can become until problems such as scale or carryover occur. A quantity of water (boiler blowdown) must continuously or periodically be removed from the boiler to regulate the concentration of impurities. There are typically two types of boiler water blowdown: bottom and surface. Bottom blowdown is a manual operation designed to remove sludge, particulates, and/or any solids settled out of the boiler water. Surface blowdown is typically a continuous discharge of dissolved solids that accumulate at the boiler water surface. The discharged boiler water

By Michael Scholnick

Garratt- Callahan Co.

ISSN:0747-8291. COPYRIGHT (C) Tall Oaks Publishing, Inc. Reproduction in whole, or in part, including by electronic means, without permission of publisher is prohibited. Those registered with the Copyright Clearance Center (CCC) may photocopy this article for a flat fee per copy. has a significant heat value that is not being used to produce steam. If the amount of blowdown can be reduced, fuel, energy, water, and treatment chemicals will be conserved.

One way of evaluating boiler blowdown reduction is as an increase in the number of times the feedwater can concentrate in the boiler (commonly referred to as *cycles of concentration* or *cycles*). Since boiler blowdown (BD) is expressed as a percentage of the total feedwater (and is calculated as the reciprocal of the number of times the feedwater can be concentrated), the more the feedwater can cycle in the boiler, the less blowdown is needed. This is illustrated in Equation 1.

$$BD = 1 \div Cycles Eq.$$

1

Where: BD = blowdown Cycles = cycles of concentration

Equation example. If the feedwater can be cycled 10 times, the blowdown rate is $1 \div 10 = 0.10$, or 10%. If the cycles can be increased to 20, the blowdown rate is $1 \div 20 = 0.5$, or 5.0%. In this example, we have increased the percentage of feedwater converted to steam from 90% to 95%. This correlates to

substantial fuel and water savings.

Minimizing Boiler Blowdown Rates Automatic blowdown control. One of the easiest methods of reducing boiler blowdown is by the installation of an automatic blowdown control system. The advantage of automated blowdown control versus manual blowdown control is that the volume of water discharged from the system is precisely correlated to the dissolved solids present. This approach contrasts with manual blowdown control where it is extremely difficult to optimize the blowdown rate.

An automated blowdown control system achieves optimum control of the boiler water chemistry. Boiler water discharge is directly correlated to the amount of total dissolved solids (TDS) by using conductivity probes. Conductivity is a reliable indicator of dissolved ions in the boiler water, with increasing conductivity equivalent to increasing TDS. The conductivity reading is compared to the programmed set-point of a conductivity controller, thereby activating the blowdown valve. The automated blowdown control system maximizes the level of solids maintained in the boiler and this directly translates to efficient boiler operation. This is illustrated in Figure 1. In the figure, A = the average



TABLE A Abbreviated Steam Table - Heat Content at Temp. and Pressure

Τ	l la at af	0	11+{	0	11+	0	11+
Temp	Heat of	Gauge	Heat of	Gauge	Heat of	Gauge	Heat of
(°F)	Liquid	Pressure	Liquid	Pressure	Liquid	Pressure	Liquid
	(Btu/lbs)	(psig)	(Btu/lb)	(psig)	(Btu/lb)	(psig)	(Btu/lb)
60	28	50	267	125	325	200	362
70	38	55	272	130	328	210	366
80	48	60	277	135	331	220	370
90	59	65	282	140	333	230	399
100	70	70	287	145	336	240	403
Gauge							
Pressure							
(psig)	—	75	290	150	338	260	385
5	196	80	294	155	341	285	394
10	208	85	298	160	344	335	410
15	219	90	302	165	346	385	424
20	228	95	305	170	348	435	437
25	236	100	309	175	351	485	450
30	243	105	312	180	353	585	472
35	250	110	316	185	355	685	493
40	256	115	319	190	357	785	512
45	262	120	322	195	360	885	530

TABLE B Approximate Btu Values and Conservative Costs

<i>Fuel</i>	<i>Btu Value/Unit</i>	<i>Costs/Unit</i>	<i>Cost/Btu</i>
#2 Oil	141,000 Btu/gal	\$0.50/gal	\$0.35/100,000 Btu
#6 Oil	152,000 Btu/gal	\$0.35/gal	\$0.23/100,000 Btu
Natural gas	1,000 Btu/ft ³	\$0.0035/ft ³	\$0.35/100,000 Btu
Coal	12,000 Btu/lb	\$35/ton	\$0.15/100,000 Btu
Hog (dry)	8,500 Btu/lb	\$30/ton	\$0.18/100,000 Btu
Hog (dry)	8,500 Btu/lb	\$30/ton	\$0.18/100,000 Btu

concentration with automatic blowdown; B = the average concentration with intermittent blowdown; C = the highest concentration just before manual blowdown; and D = the lowest concentration just after manual blowdown.

Figure 1 graphically illustrates an example of tracking boiler water solids using manual blowdown techniques versus an automated blowdown system. In the graph, when boiler water solids concentrate to the upper limit, point *C*, a manual blowdown operation is performed (the upper limit of TDS is determined by the particular boiler and any steam purity/quality requirements). Manual blowdown immediately reduces the boiler water solids to a value well below the upper limit, point *D*. As the boiler continues to steam, the solids concentrate and the cycle repeats itself. The peaks and valleys of boiler water TDS, with manual blowdown, are plotted against time.

Line *B* represents the average solids concentration, over time, in a boiler with manual blowdown. Line *A* represents the average solids concentration, over time, in a boiler using an automated blowdown control system. With automated control, solids can be continually maintained near the upper limit at all times. The difference between Line *A* and Line *B* represents savings in ener-

Need Knowledge? See our collections of text books on water treatment. Visit our web site at:

www.ultrapurewater.com

gy, water, and chemical.

Improved feedwater quality. Simply stated; the better the quality (purity) of the feedwater, the more efficient the boiler can operate. The two most common methods of improving feedwater quality are to pretreat the makeup water and to increase the percentage of returned condensate.

Pretreatment. Improving the quality of the makeup water through pretreatment methods is a common, effective way of increasing the amount of times the feedwater can be cycled within the boiler. Whether the pretreatment is designed to remove total alkalinity (expressed as $CaCO_3$), silica (SiO₂), TDS, or calcium and magnesium hardness (suspended solids), several methods of removal are available.

Although beyond the scope of this article, common treatment methods of makeup water include: filtration, ultrafil-

tration, lime-soda softening, ion exchange softening, anion exchange, dealkalization, decarbonation, evaporation, and reverse osmosis.

The makeup water quality, the steam boiler system, and the individual requirements for steam purity and steam quality determine the most effective method of pretreatment. By calculating which impurities limit the concentration of the feedwater in the boiler, we can determine what type of pretreatment will be the most cost effective.

Returned Condensate

In a properly operating steam generating system, returned steam condensate is essentially pure water. As more condensate is returned, the makeup water impurities are diluted, and the feedwater quality is proportionately improved. In a typical system, an increase in condensate return equals an increase in the cycles of concentration. As previously discussed, an increase in cycle of concentration means less boiler water blowdown, and hence, lower fuel costs, water, and treatment chemical savings.

Although the focus of this article is reducing boiler blowdown, an increase in steam condensate return has added benefits. First, condensate return equates to water conservation and directly reduces the makeup water demand. Not only does makeup water have a dollar value, but also the value goes up with pretreatment. Condensate return is a high quality water that does not require pretreatment (and is typically piped directly to the feedwater storage tank). Secondly, steam condensate is hot, and therefore carries a British thermal unit (Btu)/unit value. Returning condensate equates to returning energy to the boiler system. The more energy returned means less energy is required to create steam at any given pressure.

It should be noted that if the condensate return is not properly treated, its corrosive nature can result in detrimental levels of metals and metal oxides in the feedwater system.

Calculations

Demonstrating real energy and dollar savings by reducing boiler water blowdown is a simple process. The following calculations can be used to determine the fuel cost at the current blowdown rate vs. the fuel costs at the proposed blowdown rate. Figure 2 shows an example of a chart that could be used to

Current	Data	Proposed
l.	Boiler Water Cycles	
2.	% Blowdown	
3.	Feedwater (lb)	
k.	Blowdown (lb)	
5.	Fuel Costs (\$)	

examine heat loss and calculate potential savings. The following equations would be used to place data in the chart.

#1: Boiler water cycles of concentra-

tion. Use either actual as determined by: Boiler Water Chlorides ÷ Feedwater Chlorides, or a theoretical maximum as determined by the specific boiler the feedwater quality.

#2: % BD. Equation 2 illustrates how to calculate the blowdown percentage.

% BD = 1 ÷ Cycles Eq. 2

#3: Feedwater (FW). Equation 3 shows how to calculate the feedwater data.

 $FW = Steam \div (1 - \%BD)$ Eq. 3

Where:

Steam = steam generated in pounds (lb)

%BD = percent blowdown, as a decimal

#4: Blowdown. Equation 4 shows how to calculate the amount of blowdown.

BD = FW - Steam Eq. 4

#5: Fuel costs (FC). Equation 5 illustrates calculating the fuel cost.

FC (\$) = [BD(H_{bd})
$$\div$$
 H_f (%Eff)] × C_f
Eq. 5

Where:

BD = blowdown

 H_{bd} = heat content of blowdown, see Table A or steam tables H_{f} = heat value of fuel (Btu/unit), see Table B %Eff = boiler efficiency

 $C_{f} = \text{cost of fuel, see Table B}$

Directly Calculating Savings:

The following example demonstrates a simple way to calculate fuel savings by decreasing the boiler water blowdown.

Steam load: 1,000,000 lb/day

Boiler efficiency: 80% Boiler Pressure: 125 pounds per square inch gauge (psig) (from Table A, the total heat content of the boiler water = 325 Btu/lb)

Fuel: Natural gas (from Table B, heat content = 1,000 Btu per cubic foot [ft³], cost =\$0.0035/ ft³)

Potential savings. One may calculate the potential fuel savings that can be achieved if the percentage of returned condensate can be increased to achieve an increase in boiler water cycles (of concentration) from 10 to 20 using Equations 6 and 7.

BD at 10 cycles = 1 ÷ 10 or 10% Eq. 6

BD at 20 cycles = 1 ÷ 20 or 5.0% Eq. 7

First, calculate the actual blowdown and feedwater requirements with Equation 8.

$$FW = Steam \div (1 - \%BD)$$
 Eq. 8

Where:

FW = feedwater requirements (lb) Steam = steam generated (lb) %BD = percent blowdown, as a decimal

The calculation shows the following:

1. At 10% blowdown, FW = 1,000,000 lb ÷ (1 - 0.1) = 1,000,000 lb ÷ 0.90 = 1,111,110 lb

2. At 5% blowdown, FW = 1,000,000 lb ÷ (1 - 0.05) = 1,000,000 lb ÷ 0.95 = 1,052,632 lb

The difference in feedwater requirements represents blowdown reduction as follows:

1,111,110 lb - 1,052,632 lb = 58,478 lb in blowdown reduction.

Next, the reduction in blowdown can be converted to actual fuel savings, as seen in Equation 9.

$[BD_{r} (H_{bd}) \div H_{f} (\%Eff)] \times C_{f} = Savings in$ Fuel Costs (\$) Eq. 9	Key words: BLOWDOWN, BOILERS, ECONOMICS, STEAM, TREATMENT CHEMICALS	
Where: $BD_r = blowdown reduction$ $H_{bd} = heat content of blowdown (Table A or from steam tables) H_r = heat value of fuel (Table B or Btu/ unit) %Eff = boiler efficiency C_r = cost of fuel$		
Using the data from Equation 9, one can derive the following calculation:		
$ \begin{array}{l} [58,478 \mbox{ lb } (325 \mbox{ Btu/lb}) \div 1,000 \mbox{ Btu/ ft}^3 \\ (0.80)] \times \$0.0035/ \mbox{ ft}^3 = [19,005,350 \div \\ 800] \times 0.0035 = \$83.15/\mbox{day, or more} \\ \mbox{than } \$30,000 \mbox{ dollars a year in fuel savings.} \end{array} $		
Summary We have just demonstrated, using very conservative fuel costs and steaming rates, that by simply increasing the boil- er water cycles of concentration from 10 to 20, a savings of \$30,000/year in fuel can be achieved. In fact, if water and treatment chemical savings are also factored in, even more savings can be realized. In conclusion, if energy ac- counts for as much as 60% of a facilities overhead, and the largest energy con- sumer is the steam generating plant, then now is the time to implement mea- sures to reduce boiler water blowdown. How much can you save?		
Bibliography		
Alton, G.L. "Conservation in Boiler Water and Cooling Water Systems", National Asso- ciation of Corrosion Engineers, Milwau- kee, Wis. (March 1985).		
U.S. Department of Energy, Office of Indus- trial Technologies, Energy Efficiency and Renewable Energy, Reviewed by DOE Best Practices Steam Technical Subcom- mittee, Sheet #9 (October 2003).		
U.S. Department of Energy, Office of Indus- trial Technologies, Energy Efficiency and Renewable Energy, Reviewed by DOE Best Practices Steam Technical Subcom- mittee, Sheet #23 (April 2004).		
Author Michael Scholnick has more than 12 years of water treatment industry experience. He is a senior product man- ager for boiler chemicals at Garratt-Cal- lahan where he specializes in chemical treatment and corrosion studies.		