

Calcium Hardness Drop Count Test Procedure

1 drop = 10 ppm as CaCO_3

FOR BEST ACCURACY (1) ENSURE ACCURATE SAMPLE SIZE. (2) HOLD DROPPER BOTTLE VERTICALLY, NOT AT AN ANGLE.

1 Rinse vial 3 times with the solution to be tested. Fill vial to 25 mL with sample.



2 Add 5 drops of Calcium Hardness Buffer (CA1119) and swirl to mix.



3 Add 1 scoop of Calcium Hardness Indicator Powder (CA1100) and swirl to mix. The sample will turn red if hardness is present.



4 Add Hardness Titrant drop-wise, while swirling, until the sample color changes from red to blue. Record the number of drops.



5 Record results.

of drops x 10 = ppm as CaCO_3

Safety Tips

- Wear appropriate safety equipment.
- Read MSDS before use.

Tech Tips

- Be sure there is adequate lighting during testing
- Rinse test vial 3 times with solution to be tested.
- Hold reagent bottles vertically for best results.
- Make sure you have an accurate sample.

WATERTECH
of America, Inc.

5000 South 110th Street
Greenfield, Wisconsin 53228
P: 414.425.3339 F: 414.425.3362
E: info@WATERTECHusa.com

EndPoint ID®
Test Procedure
+PLUS

REV 5/08